





genie. II linear


INSTALL THE CAPSTAN /

01 Align the markings and insert the Capstan.

02 Turn the Capstan counter clockwise until you hear a **CLICK!**



Correct Rope Direction




Incorrect Rope Direction

i The rope shouldn't exit the channels and cross back over itself.

REMOVE THE CAPSTAN /

01 Push the Capstan Release button and hold in.

02 Turn the Capstan clockwise and pull it out to remove it.




THREAD THE CAPSTAN /

01 Holding the Capstan with the bayonet end down, thread the rope in through the bottom channel from the right to the left.



02 Thread the rope around the Capstan until you can count 4 rope winds through the capstan window.

03 Pull the rope up out through the top channel.

i The Capstan is pre-wound, avoid removing unless absolutely necessary.



i Wind 4x around



STAY IN TOUCH /

Please stay in touch with us, join our community and show us your work.

www.syrp.co



youtube.com/syrptube



vimeo.com/syrp



instagram.com/syrp_



facebook.com/syrp.co.nz



twitter.com/syrp_



syrp@syrp.co.nz

